

OWNER'S MANUAL

LED LCD MONITOR

(LED Monitor*)

* LG LED Monitor applies LCD screen with LED backlights.

Please read this manual carefully before operating your set and retain it for future reference.

24MS500	24MS550	24BA400
25MS500	25MS550	27BA400
27MS500	27MS550	

www.lg.com

TABLE OF CONTENTS

LICENSE	2
ASSEMBLING AND PREPARING	3
USING THE MONITOR	10
USER SETTINGS	12
TROUBLESHOOTING	20
PRODUCT SPECIFICATION	21

LICENSE

Each model has different licenses. Visit www.lg.com for more information on the license.



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

ASSEMBLING AND PREPARING

? CAUTION

- · Always use genuine LG components to ensure safety and product performance.
- The product warranty will not cover damage or injury caused by the use of unauthorized components.
- It is recommended to use the supplied components.
- If you use generic cables not certified by LG, the screen may not display or there may be image problems.
- Illustrations in this document represent typical procedures, so they may look different from the actual product.
- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product. (Doing so may damage the product.)
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this
 way will not be covered by the product warranty.
- Do not carry the monitor upside down by just holding the base. This may cause the monitor to fall off the stand and could result in personal injury.
- When lifting or moving the monitor, do not touch the monitor screen. The force applied to the monitor screen
 may cause damage to it.

NOTE

- The components may look different from those illustrated here.
- Without prior notice, all product information and specifications contained in this manual are subject to change to improve the performance of the product.
- To purchase optional accessories, visit an electronics store or an online shopping site, or contact the retailer from which you purchased the product.
- The power cord provided may differ depending upon the region.

Supported Drivers and Software

You can download and install the latest version from the LGE website (www.lq.com).

Drivers and Software	Installation Priority
Monitor Driver	Recommended
OnScreen Control	Recommended

Product and Button Description

Joystick Button

24MS500 25MS500 27MS500 24BA400 27BA400







How to Use the Joystick Button

You can easily control the functions of the monitor by pressing the joystick button or moving it left/right/up/down with your finger.

Basic Functions

	&	Power on	Press the joystick button once with your finger to turn on the monitor.
		Power off	Press and hold the joystick button once with your finger to turn off the monitor.
	⋖/ ▶	Volume control	You can control the volume by moving the joystick button left/right.




• The joystick button is located at the bottom of the monitor.

Moving and Lifting the Monitor


When moving or lifting the monitor, follow these instructions to prevent the monitor from being scratched or damaged and to ensure safe transportation, regardless of its shape or size.

- Place the monitor in the original box or packing material before attempting to move it.
- Before moving or lifting the monitor, disconnect the power cord and all other cables.
- Hold the bottom and side of the monitor frame firmly. Do not hold the panel itself.
- When holding the monitor, the screen should face away from you to prevent it from being scratched.
- When transporting the monitor, do not expose the monitor to shock or excessive vibration.
- When moving the monitor, keep it upright and never turn the monitor on its side or tilt it sideways.





24MS550 25MS550 27MS550





! CAUTION

- Avoid touching the monitor screen as much as possible.
 - This may result in damage to the screen or some of the pixels used to create images.






• If you use the monitor panel without the stand base, its joystick button may cause the monitor to become unstable and fall, resulting in damage to the monitor or human injury. In addition, this may cause the joystick button to malfunction.

Installing on a Table

• Lift the monitor and place it on the table in an upright position. Place the monitor at least 100 mm (3.94 inches) away from the wall to ensure sufficient ventilation.




! CAUTION

- Unplug the power cord before moving or installing the monitor. There is risk of electric shock.
- Make sure to use the power cord that is provided in the product package and connect it to a grounded power outlet.
- If you need another power cord, please contact your local dealer or the nearest retail store.

Adjusting the Stand Height

24MS550 25MS550 27MS550

- Place the monitor mounted on the stand base in an upright position.
- Handle the monitor with both hands for safety.



WARNING

• When adjusting the screen height, do not place your hand on the stand body to avoid injury to your fingers.


Adjusting the Angle

- Place the monitor mounted on the stand base in an upright position.
- 2 Adjust the angle of the screen.

The angle of the screen can be adjusted forward or backward from -5° to 15° for a comfortable viewing experience.



- To avoid injury to the fingers when adjusting the screen, do not hold the lower part of the monitor's frame as illustrated below.
- Be careful not to touch or press the screen area when adjusting the angle of the monitor.




Using the Kensington Lock

The Kensington security system connector is located at the back of the Monitor set.

For more information on installation and usage, refer to the Kensington lock owner's manual or visit the website at http://www.kensington.com.

Connect the monitor to a table using the Kensington security system cable.





• The Kensington security system is optional. You can obtain optional accessories from most electronics stores.

Installing the Wall Mount Plate


This monitor meets the specifications for the wall mount plate or other compatible devices.



- The wall mount plate is sold separately.
- For more information on installation, refer to the wall mount plate's installation guide.
- Be careful not to apply too much force while mounting the wall mount plate as it may cause damage to the screen.
- Remove the stand before installing the monitor on a wall mount by performing the stand attachment in reverse.

Installing on the Wall

Install the monitor at least 100 mm (3.94 inches) away from the wall and leave about 100 mm (3.94 inches) of space at each side of the monitor to ensure sufficient ventilation. Detailed installation instructions can be obtained from your local retail store. Alternatively, please refer to the manual for how to install and set up a tilting wall mounting bracket.



To install the monitor to a wall, attach a wall mounting bracket (optional) to the back of the monitor. Make sure that the wall mounting bracket is securely fixed to the monitor and to the wall.

Wall Mount (mm)	75 x 75
Standard screw	M4 x L10
Number of screws	4
Wall Mount Plate (Optional)	LSW 149




NOTE

- A non-VESA standard screw may damage the product and cause the monitor to fall. LG Electronics is not liable for any accidents relating to the use of non-standard screws.
- The wall mount kit includes the installation guide and all necessary parts.
- The wall mounting bracket is optional. You can obtain optional accessories from your local dealer.
- The length of the screw may differ for each wall mounting bracket. If you use screws longer than the standard length, it may damage the inside of the product.
- For more information, please refer to the user manual for the wall mounting bracket.

! CAUTION

- Unplug the power cord before moving or installing the monitor to avoid electric shock.
- Installing the monitor on the ceiling or on a slanted wall may result in the monitor falling off, which could lead to injury. Use an authorized LG wall mount and contact the local dealer or qualified personnel.
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this
 way will not be covered by the product warranty.
- Use the wall mounting bracket and screws that conform to VESA standards. Damage caused by the use or misuse of inappropriate components will not be covered by the product warranty.
- When measured from the back of the monitor, the length of each installed screw must be 8 mm(0.3 inches)
 or less.



USING THE MONITOR

• Illustrations in this manual may differ from the actual product.



- Do not press the screen for a prolonged time. This may cause image distortion.
- Do not display a still image on the screen for a prolonged time. This may cause image retention. Use a PC screensaver if possible.
- When connecting the power cord to the outlet, use a grounded (3-hole) power strip or a grounded power outlet.
- The monitor may flicker when turned on in an area where the temperature is low. This is normal.
- Sometimes red, green, or blue spots may appear on the screen. This is normal.

Connecting to a PC

- This monitor supports the *Plug and Play feature.
- * Plug and Play: A feature that allows you to add a device to your computer without having to reconfigure anything or install any manual drivers.

HDMI Connection

Transmits digital video and audio signals from your PC to the monitor.

! CAUTION

- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
 - High-Speed HDMI[®]/™ cable
- High-Speed HDMI $^{\!\!^{\circ}/TM}$ cable with Ethernet

Connecting AV Devices

HDMI Connection

HDMI transmits digital video and audio signals from your AV device to the monitor.



- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
 - High-Speed HDMI*/TM cable
 - High-Speed HDMI[®]/TM cable with Ethernet

Connecting Peripherals

Connecting Headphones

Connect peripherals to the monitor via the headphones port.



- Peripheral devices are sold separately.
- If you use angled earphones, it may cause a problem with connecting another external device to the monitor.
 Therefore, it is recommended to use straight earphones.





Straight (Recommend)

 Depending on the audio settings of the PC and external device, headphones and speaker functions may be limited.

USER SETTINGS



- Your monitor's OSD (On Screen Display) may differ slightly from that shown in this manual.
- When **Beep Guide** is activated, pressing the joystick button will take you to **Settings** right away.


Activating the Main Menu



- Press the joystick button on the bottom of the monitor.
- 2 Move the joystick up/down and left/right to set the options.
- 3 Press the joystick button once more to exit the main menu.

Button	Menu Status		Description
	Main me	nu disabled	Enables the main menu.
Main menu enabled		nu enabled	Exits the main menu. (Holding down the button to turn off the monitor. You can turn off the monitor this way at any time, including when the OSD is on.)
		Main menu disabled	Adjusts the monitor volume level.
		Main menu enabled	Enters the Input features.
		Main menu disabled	Adjusts the monitor volume level.
	Main menu enabled		Enters the Settings feature.
A		Main menu disabled	Enters the Accessibility menu.
	_	Main menu enabled	Turns off the monitor.
		Main menu disabled	Enters the Accessibility menu.
V	"	Main menu enabled	Enters the Picture Mode feature.

Main Menu Features



Main Menu	Description	
Input	Sets input mode.	
Power Off	Turns off the monitor.	
Settings	Configures the screen settings.	
Picture Mode	Sets the picture mode.	
Exit	Exits the main menu.	

Menu Settings

- 1 To view the OSD menu, press the joystick button at the bottom of the monitor and then enter the **Settings**.
- 2 Move the joystick up/down and left/right to set the options.
- 3 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (ೕ಄) it.
- 4 If you want to exit the OSD menu, move the joystick to ◀until you exit.









Quick Settings

Input

Picture

General

Customizing settings

Quick Settings

Settings > Quick Settings	Description			
Brightness	Nicote de color contrata e de Color con Cale con con			
Contrast	djusts the color contrast and brightness of the screen.			
Volume	Adjusts the volume level.			

Input

Settings > Input	Description		
Input List	Selects the input mode.		
	Adjusts the aspect ratio of the screen.	Adjusts the aspect ratio of the screen.	
	Full Wide Displays the video in wide-screen, regardless of the video signal input.		
Aspect Ratio	Original	Displays video according to the aspect ratio of the video signal input.	
	● NOTE		
	The options may disabled at the recommended resolution (1920 x 1080).		
Auto Imput Cuitah	On	Enables Auto Input Switch .	
Auto Input Switch	Off	Disables Auto Input Switch.	

Picture

Settings > Picture	Description		
Custom		Allows the user to adjust each element. The color mode of the main menu can be adjusted.	
	Reader	Optimizes the screen for viewing documents. You can brighten the screen in the OSD menu.	
	Photo	Optimizes the screen to view photos.	
Picture Mode	Cinema	Optimizes the screen to improve the visual effects of a video.	
	Color Weakness	This mode is for users who cannot distinguish between red and green. It enables users with color weakness to easily distinguish between the two colors.	
	Game	Optimizes the screen for gameplay.	

NOTE

- If the **Picture Mode** is changed, the screen may flicker or the resolution of your PC screen may be affected.
- This is subsidiary for color weakness user. Therefore if you feel uncomfortable with the screen, please turn off this function.
- This function can't distinguish some colors in some images.

Settings > Picture	Description			
	Brightness	Adjusts the brightness of the screen.		
	Contrast	Adjusts the contrast of the so	creen.	
	Sharpness	Adjusts the sharpness of the screen.		
		High	Optimized picture quality is displayed when a user wants crystal clear images. It is effective for high quality video or game.	
		Middle	The optimized picture quality is displayed when a user wants images between low and high modes for comfortable viewing. It is effective for UCC or SD video.	
Picture Adjust	SUPER RESOLUTION+	Low	The optimized picture quality is displayed when a user wants smooth and natural images. It is effective for slow-moving pictures or still images.	
		Off	Select this option for everyday viewing. SUPER RESOLUTION+ is turned off in this mode.	
		NOTE		
		Because this is a function to increase the sharpness of low resolution pictures, it is not recommended to use the function for normal text or for desktop icons. Doing so may result in unnecessarily high sharpness.		
			Sets the offset level. Offset: as a reference for a video signal, this is the darkest color the monitor can display.	
	Black Level	High	Keeps the current contrast ratio of the screen.	
		Low	Lowers the black levels and raises the white levels from the current contrast ratio of the screen.	
	DFC	On	Adjusts the brightness automatically according to the screen.	
	DEC	Off	Disables the DFC feature.	

	Response Time	Sets a response time for displayed pictures based on the speed of the screen. For a normal environment, it is recommended that you use Fast . For a fast-moving picture, it is recommended that you use Faster . Once Faster Mode is selected, Motion Blur may occur depending on the content.		
		Faster	Sets the response time to faster .	
		Fast	Sets the response time to fast .	
Game Adjust		Normal	Sets the response time to normal .	
		Off	Does not use the response time improvement feature.	
	Black Stabilizer	You can control the black contrast to have better visibility in dark scenes. Increasing the Black Stabilizer value brightens the low gray level area on the screen. (You can easily distinguish objects on dark game screens.) Reducing the Black Stabilizer value darkens the low gray level area and increases the dynamic contrast on the screen.		
	Crosshair	Crosshair provides a mark on the center of the screen for First Person Shooter (FPS) games. Users can select the Crosshair that fits their gaming environment among four different cross hairs.		
	Gamma	Mode 1, Mode 2, Mode 3	The higher the gamma value, the darker the image becomes. Likewise, the lower the gamma value, the lighter the image becomes.	
		Mode 4	If you do not need to adjust the gamma settings, select Mode 4.	
Color Adjust	ColorTemp	Selects the factory default picture color. Custom: The user can adjust it to red, green or blue by customization. Warm: Sets the screen color to a reddish tone. Medium: Sets the screen color between a red and blue tone. Cool: Sets the screen color to a bluish tone.		
	Red			
	Green	You can customize the picture color using Red, Green, and Blue colors.		
	Blue			

Picture Reset	Do you want to reset your picture settings?	No	Cancel the select.
		Yes	Returns to the default settings.

General

Settings > General	Description			
Language	To choose the language in which the control names are displayed.			
	High Enables SMART ENERGY SAVING you can save energy with this energy- high efficient.			
SMART ENERGY SAVING	Low	Enables SMART ENERG	Y SAVING you can save energy with this energy- low efficient.	
SWART ENERGY SAVING	Off	Disables SMART ENERG	SY SAVING .	
	* SMART ENERGY SAVING : Conserve	* SMART ENERGY SAVING : Conserve energy by using luminance compensation algorithm.		
Automatic Standby	Feature that automatically turns off the monitor when there is no movement on the screen for a period of time. You can set a timer for the auto-off function. (8H, 6H, 4H and 0ff)			
	Prevents incorrect key input.	out.		
	On	n Key input is disabled.		
OSD Lock	♠ NOTE			
	All function except for the OSD Lock	mode, brightness, Conti	rast, Input, Information and Volume are disabled.	
	Off	Key input is enabled.		
Information	The display information will be shown the Total Power On Time , Resolution .			
Donat	Do you want to reset your	No	Cancel the select.	
Reset settings?		Yes	Returns to the default settings.	

NOTE

- The value of energy saving data may differ depending on panel and panel suppliers.
- If you select the option of **SMART ENERGY SAVING** is **High** or **Low**, monitor luminance become lower or higher depend on source.

TROUBLESHOOTING

Check the following before calling for service.

No image appears			
Is the power cord of the display connected?	Check and see if the power cord is connected properly to the power outlet.		
Do you see an "Out of Range" message on the screen?	This message appears when the signal from the PC (video card) is out of horizontal or vertical frequency range of the display. See the 'Specifications' section of this manual and configure your display again.		
Do you see a "NO SIGNAL" message on the screen?	on the screen? • After the monitor is on "NO SIGNAL", the monitor goes to DPM mode.		
	• This is displayed when the signal cable between the PC and the monitor is missing or disconnected. Check the cable and reconnect it.		
Can 't you control some functions in OSD?			
Can't you select some menu in OSD?	You can unlock the OSD controls at any time by entering the OSD lock menu and changing items to off.		

! CAUTION

- Check Control Panel ► Display ► Settings and see if the frequency or the resolution were changed. If yes, readjust the video card to the recommend resolution.
- If the recommended resolution (optimal resolution) is not selected, letters may be blurred and the screen may be dimmed, truncated or biased. Make sure to select the recommend resolution.
- The setting method can differ by computer and 0/S (Operation System), and resolution mentioned above may not be supported by the video card performance. In this case, please ask to the computer or the video card manufacturer.

Display image is incorrect			
The screen color is mono or abnormal.	Check if the signal cable is properly connected and use a screwdriver to fasten if necessary.		
	Make sure the video card is properly inserted in the slot.		
	• Set the color setting higher than 24 bits (true color) at Control Panel ▶ Settings .		
The screen blinks.	Check if the screen is set to interlace mode and if yes, change it to the recommend resolution.		
Do you see an "Unrecognized monitor, Plug&Play	Do you see an "Unrecognized monitor, Plug&Play (VESA DDC) monitor found" message?		
Have you installed the display driver?	Be sure to install the display driver from our web site: http://www.lg.com.		
Make sure to check if the video card supports Plug&Play function.			
The screen is flickering.			
Did you select the recommended resolution?	• If the selected resolution is HDMI 1080i 60/50 Hz, the screen may be flickering. Change the resolution to the recommended resolution 1080P.		

24MS500

Color Depth	8-bit color is supported.		
Resolution	Max Resolution	1920 x 1080 @ 100 Hz	
	Recommended Resolution	1920 x 1080 @ 100 Hz	
Power Sources	Power Rating	19 V 0.84 A	
AC/DC adaptor	Type ADS-25FFA-19-3 19016E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPCU-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPI-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPG, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD10570LF, manufactured by PI Electronics (H.K.) Ltd., or Type AD2152S20, manufactured by PI Electronics (H.K.) Ltd., or Type AD2152620, manufactured by PI Electronics (H.K.) Ltd Output: 19 V = 0.84 A		
	Operating Conditions	Temperature	0 °C to 40 °C
Environmental Conditions		Humidity	Less than 80 %
	Storing Conditions	Temperature	-20 °C to 60 °C
	Storing Conditions		Less than 85 %

	Monitor Size (Width x Height x Depth)		
Dimensions	With Stand	539.9 x 414.4 x 190.0 (mm)	21.2 x 16.3 x 7.4 (inches)
	Without Stand	539.9 x 321.4 x 56.2 (mm)	21.2 x 12.6 x 2.2 (inches)
Weight (Without Packaging)	With Stand	2.6 kg	5.7 lbs
	Without Stand	2.3 kg	5.0 lbs

The symbol \sim means alternating current, and the symbol $\frac{1}{2}$ means direct current.

24MS550

Color Depth	8-bit color is supported.			
D lasta	Max Resolution	1920 x 1080 @ 100 Hz		
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz		
Power Sources	Power Rating	19 V 1.3 A		
AC/DC adaptor	Type ADS-25FFA-19-3 19025E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FFSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD10560LF, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139S20, manufactured by PI Electronics (H.K.) Ltd., Output: 19 V = 1.3 A			
	Operating Conditions	Temperature Humidity	0 °C to 40 °C Less than 80 %	
Environmental Conditions		Temperature	-20 °C to 60 °C	
	Storing Conditions	Humidity	Less than 85 %	

	Monitor Size (Width x Height x Depth)		
Dimensions	With Stand	539.9 x 447.6 x 219.4 (mm)	21.2 x 17.6 x 8.6 (inches)
	Without Stand	539.9 x 321.4 x 56.2 (mm)	21.2 x 12.6 x 2.2 (inches)
Weight (Without Packaging)	With Stand	3.2 kg	7.0 lbs
	Without Stand	2.4 kg	5.2 lbs

The symbol \sim means alternating current, and the symbol === means direct current.

25MS500

	1			
Color Depth	8-bit color is supported.			
Resolution	Max Resolution	1920 x 1080 @ 100 Hz		
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz		
Power Sources	Power Rating	19 V 0.84 A		
AC/DC adaptor	Type ADS-25SFA-19-3 19016E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPCU-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19016EPG, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD10570LF, manufactured by PI Electronics (H.K.) Ltd., or Type AD2152S20, manufactured by PI Electronics (H.K.) Ltd., or Type AD2152620, manufactured by PI Electronics (H.K.) Ltd			
	Operating Conditions	Temperature	0 °C to 40 °C	
Environmental Conditions		Humidity	Less than 80 %	
Environmental conditions	Storing Conditions	Temperature	-20 °C to 60 °C	
Storing Conditions		Humidity	Less than 85 %	

	Monitor Size (Width x Height x Depth)		
Dimensions	With Stand	557.5 x 421.2 x 190.0 (mm)	21.9 x 16.5 x 7.4 (inches)
	Without Stand	557.5 x 328.3 x 58.8 (mm)	21.9 x 12.9 x 2.3 (inches)
Weight (Without Packaging)	With Stand	2.6 kg	5.7 lbs
	Without Stand	2.3 kg	5.0 lbs

The symbol \sim means alternating current, and the symbol === means direct current.

25MS550

Color Depth	8-bit color is supported.			
D lost	Max Resolution	1920 x 1080 @ 100 Hz		
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz		
Power Sources	Power Rating	19 V 1.3 A		
AC/DC adaptor	Type ADS-25FFA-19-3 19025E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FFF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD2139S20, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139S20, manufactured by PI Electronics (H.K.) Ltd Output: 19 V = 1.3 A			
	Operating Conditions	Temperature Humidity	0 °C to 40 °C Less than 80 %	
Environmental Conditions	5. 1. 6. 10.	Temperature	-20 °C to 60 °C	
	Storing Conditions	Humidity	Less than 85 %	

	Monitor Size (Width x Height x Depth)		
Dimensions	With Stand	557.5 x 475.2 x 219.4 (mm)	21.9 x 18.7 x 8.6 (inches)
	Without Stand	557.5 x 328.3 x 58.8 (mm)	21.9 x 12.9 x 2.3 (inches)
Weight (Without Packaging)	With Stand	3.1 kg	6.8 lbs
	Without Stand	2.3 kg	5.0 lbs

The symbol ~ means alternating current, and the symbol ____ means direct current.

27MS500

Color Depth	8-bit color is supported.		
Developing	Max Resolution	1920 x 1080 @ 100 Hz	
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz	
Power Sources	Power Rating	19 V 1.3 A	
AC/DC adaptor	Type ADS-25FFA-19-3 19025E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD10560LF, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139S20, manufactured by PI Electronics (H.K.) Ltd., Or Type AD2139620, manufactured by PI Electronics (H.K.) Ltd		
	Operating Conditions	Temperature Humidity	0 °C to 40 °C Less than 80 %
Environmental Conditions	Storing Conditions	Temperature	-20 °C to 60 °C
	Joining Conditions	Humidity	Less than 85 %

	Monitor Size (Width x Height x Depth)		
Dimensions	With Stand	612.0 x 454.9 x 190.0 (mm)	24 x 17.9 x 7.4 (inches)
	Without Stand	612.0 x 362.5 x 56.2 (mm)	24 x 14.2 x 2.2 (inches)
Wainht (Without Dadraning)	With Stand	3.5 kg	7.7 lbs
Weight (Without Packaging)	Without Stand	3.1 kg	6.8 lbs

The symbol ~ means alternating current, and the symbol === means direct current.

27MS550

Color Depth	8-bit color is supported.		
Developing	Max Resolution	1920 x 1080 @ 100 Hz	
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz	
Power Sources	Power Rating	19 V 1.3 A	
AC/DC adaptor	Type ADS-25SFA-19-3 19025E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD10560LF, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139S20, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139620, manufactured by PI Electronics (H.K.) Ltd		
	Operating Conditions	Temperature Humidity	0 °C to 40 °C Less than 80 %
Environmental Conditions		Temperature	-20 °C to 60 °C
	Storing Conditions	Humidity	Less than 85 %

	Monitor Size (Width x Height x Depth)			
Dimensions	With Stand	612.0 x 492.1 x 219.4 (mm)	24 x 19.3 x 8.6 (inches)	
	Without Stand	612.0 x 362.5 x 56.2 (mm)	24 x 14.2 x 2.2 (inches)	
Waight (Without Darkaging)	With Stand	3.9 kg	8.5 lbs	
Weight (Without Packaging)	Without Stand	3.1 kg	6.8 lbs	

The symbol ~ means alternating current, and the symbol === means direct current.

24BA400

Color Depth	8-bit color is supported.				
D lasta	Max Resolution	1920 x 1080 @ 100 Hz			
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz	1920 x 1080 @ 100 Hz		
Power Sources	Power Rating	19 V 1.3 A			
AC/DC adaptor	Type ADS-25SFA-19-3 19025E, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPCU-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPG-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type ADS-25FSF-19 19025EPB-1, manufactured by SHENZHEN HONOR ELECTRONIC, or Type AD10560LF, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139520, manufactured by PI Electronics (H.K.) Ltd., or Type AD2139620, manufactured by PI Electronics (H.K.) Ltd Output: 19 V =1.3 A				
	Operating Conditions	Temperature	0 °C to 40 °C		
Environmental Conditions		Humidity	Less than 80 %		
	Storing Conditions	Temperature	-20 °C to 60 °C		
	Storing Conditions	Humidity	Less than 85 %		

	Monitor Size (Width x Height x Depth)		
Dimensions	With Stand	539.9 x 414.4 x 190 (mm)	21.2 x 16.3 x 7.4 (inches)
	Without Stand	539.9 x 321.4 x 56.2 (mm)	21.2 x 12.6 x 2.2 (inches)
Woight (Without Darkaning)	With Stand	2.7 kg	5.9 lbs
Weight (Without Packaging)	Without Stand	2.4 kg	5.2 lbs

The symbol ~ means alternating current, and the symbol === means direct current.

27BA400

Color Depth	8-bit color is supported.			
Developing	Max Resolution	1920 x 1080 @ 100 Hz		
Resolution	Recommended Resolution	1920 x 1080 @ 100 Hz		
Power Sources	Power Rating	19 V 1.3 A		
AC/DC adaptor	Type ADS-25SFA-19-3 19025E, manufactured by SI- or Type AD10560LF, manufactured by PI Electronics Output: 19 V = 1.3 A			
	Operating Conditions	Temperature	0 °C to 40 °C	
Environmental Conditions		Humidity	Less than 80 %	
Environmental Conditions	Storing Conditions	Temperature	-20 °C to 60 °C	
		Humidity	Less than 85 %	
	Monitor Size (Width x Height x Depth)			
Dimensions	With Stand	612.0 x 454.9 x 190 (mm)	24 x 17.9 x 7.4 (inches)	
	Without Stand	612.0 x 362.5 x 56.2 (mm)	24 x 14.2 x 2.2 (inches)	
Woight (Without Packaging)	With Stand	3.5 kg	7.7 lbs	
Weight (Without Packaging)	Without Stand	3.1 kg	6.8 lbs	

The specifications are subject to change without notice.

The symbol ~ means alternating current, and the symbol — means direct current.

Factory Support Mode (Preset Mode, PC)

HDMI

Preset Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Polarity (H/V)	Remarks
640 x 480	31.469	59.94	-/-	
800 x 600	37.879	60.317	+/+	
1024 x 768	48.363	60.004	-/-	
1280 x 720	45	60	+/+	
1280 x 1024	79.976	75.025	+/+	
1920 x 1080	67.5	60	+/+	
1920 x 1080	66.587	59.934	+/-	
1920 x 1080	83.894	74.973	+/+	
1920 x 1080	110	100	+/-	Recommended timing

HDMI Timing (Video)

Factory support mode (Preset Mode)	Horizontal Frequency(kHz)	Vertical Frequency(Hz)	НДМІ
480P	31.5	60	0
720P	45.0	60	0
1080P	67.5	60	0
1080P	67.5	60	Recommend Mode

Beep Guide

Quick Settings	1
Outals Cattinus Drinktoness	
Quick Settings - Brightness	11
Quick Settings - Brightness	111 Slider
Quick Settings - Contrast	12
Quick Settings - Contrast	1 2 1 Slider
Quick Settings - Volume	13
Quick Settings - Volume	131Slider
Input	2
Input - Input List	21
Input - Input List - HDMI1	211
Input - Input List - HDMI2	212
Input - Aspect Ratio	22
Input - Aspect Ratio - Full Wide	221
Input - Aspect Ratio - Original	222
Input - Auto Input Switch	23
Input - Auto Input Switch - On	231
Input - Auto Input Switch - Off	232
Picture	3
Picture - Picture Mode	31
Picture - Picture Mode - Custom	311
Picture - Picture Mode - Reader	312
Picture - Picture Mode - Photo	313
Picture - Picture Mode - Cinema	314
Picture - Picture Mode - Color Weakness	315
Picture - Picture Mode - Game	316

Menu	Location
Picture - Picture Adjust	32
Picture - Picture Adjust - Brightness	321
Picture - Picture Adjust - Brightness	3 2 1 1 Slider
Picture - Picture Adjust - Contrast	322
Picture - Picture Adjust - Contrast	3 2 2 1 Slider
Picture - Picture Adjust - Sharpness	323
Picture - Picture Adjust - Sharpness	3 2 3 1 Slider
Picture - Picture Adjust - SUPER RESOLUTION+	324
Picture - Picture Adjust - SUPER RESOLUTION+ - High	3241
Picture - Picture Adjust - SUPER RESOLUTION+ - Middle	3242
Picture - Picture Adjust - SUPER RESOLUTION+ - Low	3243
Picture - Picture Adjust - SUPER RESOLUTION+ - Off	3244
Picture - Picture Adjust - Black Level	325
Picture - Picture Adjust - Black Level - High	3251
Picture - Picture Adjust - Black Level - Low	3252
Picture - Picture Adjust - DFC	326
Picture - Picture Adjust - DFC - On	3261
Picture - Picture Adjust - DFC - Off	3262
Picture - Game Adjust	33
Picture - Game Adjust - Response Time	331
Picture - Game Adjust - Response Time - Faster	3311
Picture - Game Adjust - Response Time - Fast	3312
Picture - Game Adjust - Response Time - Normal	3313
Picture - Game Adjust - Response Time - Off	3314
Picture - Game Adjust - Black Stabilizer	332

Menu	Location
Picture - Game Adjust - Black Stabilizer	3 3 2 1 Slider
Picture - Game Adjust - Crosshair	333
Picture - Game Adjust - Crosshair - Red Cross	3331
Picture - Game Adjust - Crosshair - Green Cross	3332
Picture - Game Adjust - Crosshair - Red Dot	3333
Picture - Game Adjust - Crosshair - Green Dot	3334
Picture - Game Adjust - Crosshair - Off	3335
Picture - Color Adjust	3 4
Picture - Color Adjust - Gamma	3 4 1
Picture - Color Adjust - Gamma - Mode 1	3411
Picture - Color Adjust - Gamma - Mode 2	3412
Picture - Color Adjust - Gamma - Mode 3	3413
Picture - Color Adjust - Gamma - Mode 4	3414
Picture - Color Adjust - Color Temp	3 4 2
Picture - Color Adjust - Color Temp - Custom	3 4 2 1
Picture - Color Adjust - Color Temp - Warm	3422
Picture - Color Adjust - Color Temp - Medium	3423
Picture - Color Adjust - Color Temp - Cool	3 4 2 4
Picture - Color Adjust - Red	3 4 3
Picture - Color Adjust - Red	3 4 3 1 Slider
Picture - Color Adjust - Green	3 4 4
Picture - Color Adjust - Green	3 4 4 1 Slider
Picture - Color Adjust - Blue	3 4 5
Picture - Color Adjust - Blue	3 4 5 1 Slider
Picture - Picture Reset	3.5

Menu	Location
Picture - Picture Reset - No	351
Picture - Picture Reset - Yes	352
General	4
General - Language	41
General - Language - English	411
General - Language - German	412
General - Language - French	413
General - Language - Spanish	414
General - Language - Italian	415
General - Language - Swedish	416
General - Language - Finnish	417
General - Language - Portuguese	418
General - Language - Portuguese (Brazil)	419
General - Language - Polish	4110
General - Language - Russian	4111
General - Language - Turkish	4112
General - Language - Ukrainian	4113
General - Language - Chinese	4114
General - Language - Traditional Chinese	4115
General - Language - Japanese	4116
General - Language - Korean	4117
General - Language - Hindi	4118
General - Smart Energy Saving	42
General - Smart Energy Saving - High	421
General - Smart Energy Saving - Low	422
General - Smart Energy Saving - Off	423

Menu	Location
General - Automatic Standby	43
General - Automatic Standby - 4H	431
General - Automatic Standby - 6H	432
General - Automatic Standby - 8H	433
General - Automatic Standby - Off	434
General - OSD Lock	44
General - OSD Lock - On	441
General - OSD Lock - Off	442
General - Information	45
General - Information	451
General - Reset	46
General - Reset - No	461
General - Reset - Yes	462



Cumplior's	Declaration	of Con	formit
Suppliers	veciaration	or con	IOrmit

Trade Name LG

Responsible Party LG Electronics USA, Inc.

111 Sylvan Avenue, North Building, Address Englewood Cliffs, NJ 07632

lg.environmental@lge.com

E-mail

The model and serial number of the product are located on the back and on one side of the product. Record them below in case you ever need service.

Model	
Serial No	



(For 24BA400/27BA400/25MS550 only)

This Product qualifies for ENERGY STAR®

Changing the factory default configuration and settings or enabling certain optional features and functionalities may increase energy consumption beyond the limits required for ENERGY STAR® certification.

Refer to ENERGYSTAR.gov for more information on the ENERGY STAR® program.